

Task 5: Troubleshooting Scenarios

Scenario 1: Desktop Not Powering On

Problem Description

An employee's desktop computer does not switch on when the power button is pressed.

Symptoms

- No lights on the computer.
- No fan movement or sound.
- Monitor remains blank.
- Keyboard and mouse lights are off.

Possible Causes

- Power cable disconnected.
- Faulty power supply unit (PSU).
- Wall socket has no power.
- Damaged motherboard or internal hardware.
- UPS not functioning properly.

Troubleshooting Steps

1. Check that the power cable is securely connected.
2. Test the wall socket using another device.
3. Ensure the UPS is switched on and working.
4. Inspect the PSU switch at the back of the desktop.
5. Remove and reconnect internal power cables if necessary.
6. Test with a different power cable or PSU.
7. Listen for beep codes or observe motherboard indicator lights.

Resolution

The power cable was loose at the back of the desktop. After reconnecting it securely, the computer powered on successfully.

Scenario 2: No Internet Connectivity

Problem Description

Users in the office are unable to access the internet on their computers.

Symptoms

- Web pages do not load.
- “No Internet Access” message displayed.
- Wi-Fi connected but no browsing possible.
- Network icon shows limited connectivity.

Possible Causes

- ISP outage.
- Router or switch failure.
- Incorrect IP configuration.
- Damaged Ethernet cable.
- DNS server issues.
- Wi-Fi access point malfunction.

Troubleshooting Steps

1. Check if multiple users are affected.
2. Restart the router and switch.
3. Verify Ethernet cable connections.
4. Run the ipconfig command to check IP settings.
5. Ping the default gateway and external websites.
6. Test internet access on another device.
7. Contact the ISP to confirm service availability.

Resolution

The router had lost connection to the ISP. Restarting the router restored internet connectivity for all users.

Scenario 3: Printer Offline

Problem Description

Employees are unable to print documents because the shared network printer appears offline.

Symptoms

- Print jobs remain in queue.
- “Printer Offline” message displayed.
- Printer not responding to print requests.
- Printer unavailable on the network.

Possible Causes

- Printer powered off.
- Network connection disconnected.
- Printer IP address conflict.
- Print spooler service stopped.
- Outdated or corrupted printer drivers.

Troubleshooting Steps

1. Ensure the printer is powered on.
2. Check network or USB cable connections.
3. Restart the printer and computer.
4. Verify the printer is connected to the network.
5. Clear stuck print jobs from the queue.
6. Restart the Print Spooler service.
7. Reinstall or update printer drivers.

Resolution

The printer was disconnected from the network switch. After reconnecting the network cable and restarting the printer, printing services returned to normal.